



## VEHICLE TERMINAL COMPARTMENT

### NOTES:

1. INSTALL SINGLE CONDUCTOR COLOR CODED #14 THWN COPPER WIRE BETWEEN TERMINAL STRIP AND EACH SIGNAL ASSEMBLY AND CONNECT.
2. BAND LOOSELY ALL CABLES AT TERMINALS AND IN PULL BOXES WITH EMBOSSED PVC TAPE MARKED "CABLE #1 TO PHASE 2", "CABLE #2 TO PHASE 4", ETC.
3. WITHIN INDIVIDUAL CABLES THE ASSIGNMENTS OF PRIMARY OR SECONDARY COLORS ARE BASED UPON THE TABLE BELOW :

PRI	SEC
NB	EB or SB or WB
EB	SB or WB
SB	WB
THRU	TURN